**IP.**VOICE

Handset

Base Station

Navigation Button

Battery level indicator

Soft Key

On/Off Button

Lock/Unlock

Mute

Charger Cradle

IPV53

10:39
Thur. Mar 26

Kyle Wu Handset

History     Line

1 ⌒ | 2 ABC | 3 DEF
4 GHI | 5 JKL | 6 MNO
7 PQRS | 8 TUV | 9 WXYZ
* ⸱ | 0 + | # ⌂
TRAN

## Basic Operations

Turning Handset On/Off:
- Press ⌀ , then the LCD screen lights up.
- Place the Handset in the charger cradle to turn on automatically.
- Long press ⌀ again to turn the Handset off.

Locking/Unlocking keypad:
- Long press #⌂ when the Handset is idle to lock the keypad.
- Long press #⌂ again to unlock the keypad.

Switching Silent Mode On/Off:
- Long press ✳ when the Handset is idle to lock the keypad.
- Long press ✳ again to unlock the keypad.

## Make a Call

Enter the desired number when the handset, then press 📞 .

## To place a call from the local directory

1. Press ▼ when the handset is idle.
2. Select the directory.
   - Internal use directory
   - External use LDAP
3. Press ▲ or ▼ to highlight the desired entry, and then then press 📞.

## Answer a Call, do one of the following:

- Press the **Accept** soft key.
- Alternatively press 🔊 , 📞 or ok .

## Put a Call on Hold

1. Press the **Options** soft key during a call, and then select Hold.
2. To resume the call, press the **Resume** soft key.

## Access the Directory

- Press the ok key to enter the main menu, and then select **Directory** OR
- When the Handset is idle press ▼ .

## Transfer a Call to Another Person

1. Press the **Options** soft key during call, and then select Transfer.
2. Enter the number you want to transfers the call to.
3. Press **Transfer** soft key.

## Make a Call with the Speakerphone

1. Enter a number using the keypad.
2. Press **Speakerphone** 🔊 .

## Mute Your Audio

1. Press ⬛ during a call to mute the call.
2. Press ⬛ again to turn mute off.

## To end a Call

Press ⌀ .

## Listen to Your Voice Messages

Press **Messages** keys and follow the voice prompts. To check messages for a specific line, press the line button first.

## Adjust the Volume in a Call

Whilst in call, press ◄ or ►

## Adjust the Ringtone Volume

Whilst in call, press ◄ or ►

## Call Pickup

Dial *88

## View Call History

1. Press history
2. Press ▲ or ▼ to highlight the desired entry, and then then press 📞.

## Redial

1. Press the green call button.
2. Press ▲ or ▼ to highlight the desired entry, and then then press 📞.